



Tree Top 15' Deluxe Tripod

MODEL: PVTS-15R

- Weight Limit: 300 lbs.
- Do Not Over Tighten Fasteners



Thank you very
much for choosing



We appreciate
your business!



WARNING

SAFETY MUST BE YOUR FIRST PRIORITY WITH THIS PRODUCT

Every year serious injury or death can occur from hunting related accidents. To ensure your safety, please **completely** read and follow this safety manual and all warning labels **before** assembling, installing or utilizing this product.

Do not use this product before fully understanding all safety warnings and instructions. If you have questions, are unsure about any information or need additional information concerning your product, contact our customer service department at 1-866-972-6168 or visit www.Primaltreestands.com. Keep and maintain this safety and instruction manual in a safe location for future reference.

TRIPOD SAFETY WARNINGS

Please read the following instruction manual and warning labels completely before utilizing this product. Failure to understand and execute the instructions and warnings may result in serious injury or death. In the event of an accident, have a plan for rescue, including the use of devices that may be easily reached while suspended.

ALWAYS read and understand all warnings and instructions including assembly, installation etc., before each use of this product. Failure to read and understand all warnings and instructions may result in serious injury or death. Contact a Customer Service Representative with any questions you may have.

NEVER exceed total weight limit of **300 lbs.** **DO NOT** use if your combined weight with all of your hunting gear and any accessories exceeds **300 lbs.** Use of tripod over the weight limit may result in serious injury or death.

DO NOT use this tripod while under the influence of alcohol, medication or any illegal substances. Use of tripod while under the influence of any of these substances may result in serious injury or death.

NEVER use this tripod during inclement weather. **DO NOT** use Tripod during thunderstorms, snowstorms, hurricanes, tornadoes or any other weather conditions that include (but are not limited to) lightning, icy conditions, or high winds that could create slippery or dangerous situations. End your hunt and return to the ground if inclement weather conditions arise.

NEVER use tripod If you are feeling ill, nauseous, dizzy or if you have a prior condition that could cause a problem. e.g., heart condition, joints that lock-up spinal fusions, etc., or if you are not well rested and alert. Physical ailments can reduce your ability to safely install, utilize, and remove your treestand. Please consult a physician prior to use.

NEVER use this tripod if you have a history of health problems such as (but are not limited to) heart problems, back problems, high blood pressure, impaired vision, equilibrium impairments, are afraid of heights, have been advised by a doctor or physician not to climb. If you are not physically fit, well rested, and alert, or if you have any other physical or mental condition that would impair your ability to properly use this treestand.

NEVER jump or bounce on the tripod's platform or ladder sections. Instead, step firmly on the first rung of the bottom ladder section to set the ladder into the ground before proceeding to climb the ladder.

NEVER transport any of your equipment with yourself while ascending or descending the ladder. You will need to have two hands free during ascending and descending for safety. Use a haul line to pull up your firearm (unloaded, chamber opened with safety lock engaged, barrel facing towards the ground), bows, arrows, knives or any other equipment to your tripod once you have reached your desired hunting height. Prior to descending, lower your equipment on the opposite side of the tripod from which you are climbing. Make sure that the unloaded firearm's safety lock is engaged and the gun barrel is pointing towards the ground.

ALWAYS hunt with a plan and a buddy. Before you leave home, let others know your exact location, when you plan to return and who is with you.

ALWAYS carry emergency signal devices such as a cell phone, walkie-talkie, whistle, signal flare, PLD (personal location device) and flashlight with you at all times and within reach even while you are suspended in your harness. Watch for changing weather conditions. In the event of an accident, remain calm and seek help immediately.

ALWAYS inspect the tripod for signs of wear or damage **BEFORE** each use. Also inspect to ensure that nuts and bolts are secure. Destroy all products that cannot be repaired by the manufacturer. Contact a Customer Service Representative for replacement parts.

NEVER modify your tripod in any way by making repairs, replacing parts, or altering, adding or attaching anything to it except if explicitly authorized in writing by the manufacturer. Improper installation or adjustment may cause serious injury or death. Remove all contents from box. Inspect for any damaged or missing parts. If any parts are missing or damaged, you must only use certified replacement parts. Using any other replacement parts will void product warranty. **THERE ARE NO EXTRA PARTS.** All parts **MUST** be used to ensure the safety of you and your stand. If you think parts are missing or damaged, **STOP IMMEDIATELY** and contact our Customer Service Department. Using the tripod with missing or damaged parts may result in serious injury or death. **DO NOT** return this product to the retailer. Contact a Customer Service Representative if you have any missing, damaged or extra parts.

ALWAYS keep instructions in a safe place and review before each use. It is the responsibility of the tripod owner to furnish the complete instructions to anyone who borrows or purchases the treestand from you.

TRIPOD SAFETY WARNINGS

NEVER use this Tripod for any use other than hunting.

NEVER use this Tripod for trimming trees.

NEVER fall asleep in your stand as you may fall out resulting in serious injury or death.

ALWAYS be sure to retighten all bolts **BEFORE** each new use of Tripod.

ALWAYS have a minimum of three people present when installing or removing this Tripod.

NEVER adjust your stand while in use.

ALWAYS inspect every ladder section connection every time you use the stand before you leave the ground. If ladder sections are separating, with the help of at least two other people, lower the stand to the ground, make adjustments, and reinstall.

ALWAYS check the ground below the Tripod to make sure it is firm and level. Sloping ground or uneven terrain (one side of a rock or root) can cause your Tripod to tilt or shift.

ALWAYS maintain three points of contact when climbing the Tripod. (Two feet and one hand **or** one foot and two hands.)

DO NOT leave your Tripod outside since weather or animals may cause damage. It must be stored inside when not in use.

NEVER wear jewelry or loose fitting clothing, which can cause hazardous conditions. Clothing may be caught in your equipment and cause you to fall. You must always wear non-slip or rubber boots. Shoelaces must be tucked into your boots. Rings and necklaces **MUST NOT** be worn.

NEVER let children use this Tripod without adult supervision. This Tripod is not a toy. No one under the age of 18 should attempt to use this product without direct adult supervision.

DO NOT use Tripod if any nuts or bolts or parts are loose, bent, or crooked.


ALWAYS know your physical limitations. Don't take chances. If you start thinking about how high you are, don't go any higher. Instead, choose a minimum height that will allow for safe, effective and comfortable hunting.

ALWAYS lean **forward towards the ladder** as you climb. **NEVER** lean out from the Tripod for any reason.

Be aware that falls can occur at anytime after leaving the ground.

NEVER remove any safety warning stickers from this product.

Safety must be your first priority during the use of this product.













Tree Top 15' Deluxe Tripod

MODEL: PVTS-15R

- Weight Limit: 300 lbs.
- Do Not Over Tighten Fasteners



PARTS LIST

| | | |
|----------|-------------------------------|-----------------|
| A | 1 Left Platform..... | Part # PLP-600 |
| B | 1 Right Platform..... | Part # PRP-600 |
| C | 1 Seat Pedestal..... | Part # PSP-600 |
| D | 1 Seat Back..... | Part # PSB-600 |
| E | 1 Seat Platform..... | Part # PSP-610 |
| F | 2 Shooting Rails..... | Part # PSR-600 |
| G | 2 Armrests..... | Part # PAR-600 |
| H | 2 Handle Rails..... | Part # PHR-600 |
| J | 2 Rear Leg Braces..... | Part # PRLB-600 |
| L | 2 Armrest Covers..... | Part # PARC-600 |
| M | 1 Seat Cushion..... | Part # PSC-610 |
| N | 1 Seat Back Cushion..... | Part # PSC-611 |
| O | 4 Shooting Rail Covers..... | Part # PSRC-600 |
| P | 4 Shooting Rail Supports..... | Part # PSRS-600 |
| Q | 1 Skirt..... | Part # PS-650 |
| R | 2 Upper Legs..... | Part # PL-600 |
| S | 2 Lower Legs..... | Part # PL-610 |
| T | 6 Male Braces..... | Part # PB-600 |
| U | 1 Top Ladder..... | Part # PTL-600 |
| V | 1 Bottom Ladder..... | Part # PBL-600 |
| W | 3 Cross Braces..... | Part # PCB-600 |
| X | 2 Leg Feet..... | Part # PLF-650 |
| Y | 4 Anchor Pin..... | Part # PAP-600 |


HARDWARE BOX P/N 015H

| | | |
|------------|---|-----------------|
| K | 4 Support Braces..... | Part # PSRB-600 |
| Z | 1 Large Washer with M8x30mm (RED) Bolt..... | Part # 1230R |
| 110 | 2 M8x110mm (PINK) Bolt..... | Part # 12110 |
| 75 | 4 M8x75mm (PURPLE) Bolt..... | Part # 1275 |
| 65 | 4 M8x65mm (ORANGE) Bolt..... | Part # 1265 |
| 55 | 24 M8x55mm (BLACK) Bolt..... | Part # 1255 |
| 45 | 8 M8x45mm (YELLOW) Bolt..... | Part # 1245 |
| 40 | 22 M8x40mm (BLUE) Bolt..... | Part # 1240 |
| 30 | 8 M6x30mm (WHITE) Bolt..... | Part # 1030 |




ALL PHOTOS TAKEN FROM FRONT VIEW UNLESS OTHERWISE NOTED


Remove all contents from packaging and make sure all parts are present before attempting to assemble. Tighten all bolt connections by hand first and then when fully assembled, go back and tighten with a wrench.



1 Slide Left Platform **A** into Right Platform **B**. Use **1-M8x40mm BLUE Bolt (40)** on each side of platform. Use **2-M8x110mm PINK Bolt (110)** in the middle of the platform. Set aside for future use.




3 Insert the crimped end of Male Brace **T** into the end of Cross Brace **W** near the pivot point. Insert **1-M6x30mm WHITE Bolt (30)** at each point. Do this for **ALL** remaining Cross Braces. Set aside for future use.




Attach Seat Back **D** to Seat Platform **E** using **1-M8x55mm BLACK Bolt (55)** on each side.

NOTE: The plate on the Seat Platform **MUST** be on the bottom.


2 Attach Armrest **G** to Seat Back **D** and Seat Platform **E** using **2-M8x55mm BLACK Bolt (55)** at each connection point. Set aside for future use.




4 Slide both halves of Shooting Rail **F** together and secure with **1-M6x30mm WHITE Bolt (30)** on each side. Set aside for future use.




5 Turn the assembled platform over so that the top of the platform is on the ground. Attach Handle Rail **H** to the bottom of the assembled platform using **2-M8x65mm ORANGE Bolts (65)** for each Handle Rail.






7 Turn the platform upright. Attach Seat Pedestal **C** to the center of the platform using **4-M8x45mm YELLOW Bolts (45)**.




6 With the platform still upside down. Attach Rear Leg Braces **J** to the rear of the platform using **2-M8x75mm PURPLE Bolts (75)** for each Rear Leg Brace.




8 Disassemble the **RED Bolt with Large Washer (Z)**. Place the Large Washer on top of the Seat Pedestal **C**. Hold the assembled Seat on the Seat Pedestal. Place a metal washer onto the **RED** bolt, then insert a nylon washer on the bolt. Insert the bolt through the Seat Platform, Large Washer, and the Seat Pedestal. Place another nylon washer onto the bolt, then the last metal washer and tighten the nut.



- 9** Attach Shooting Rail Support **(P)** to the assembled platform using **1-M8x55mm BLACK Bolt (55)** for each piece. *(The two holes on the Shooting Rail Support will be on the bottom. See Close-Up Photos for correct placement).*
- Attach Support Brace **(K)** to the assembled platform and to the **INSIDE** of the Shooting Rail Supports using **1-M8x40mm BLUE Bolt (40)** for each connection point. *(See Close-Up Photo for correct placement).*



- 10** Attach assembled Shooting Rail **(F)** to each Shooting Rail Support **(P)** using **1-M8 x55mm BLACK Bolt (55)** at each connection point.



11

Attach each Shooting Rail Cover **O** to Shooting Rail **F**.


Attach Each Armrest Cover **L** to each Armrest **G**.

Attach Seat Back Cushion **N** to Seat Back **D**.

Attach Seat Cushion **M** to Seat Platform **E**.

12

Tie Skirt **Q** around the top of Shooting Rail and the Platform.




13

Lean the tripod on its front, so that the handle rails are on the ground and the rear leg braces are facing up.

Insert Upper Leg **R** into Rear Leg Brace **J**. (The Upper Leg has 2 holes on the Bottom). The brackets on the legs **MUST** be facing towards the inside of the stand. Secure with **2-M8x55mm BLACK Bolts** **55** on each leg.

14

BOTTOM




14

Insert Lower Leg **S** into Upper Leg **R**. (The Lower Leg has 1 hole on the Bottom). The brackets on the legs **MUST** be facing towards the inside of the stand. Secure with 2-M8x55mm **BLACK Bolts** **55** on each leg.

15



REAR VIEW



15

Attach one Cross Brace **W** to the Upper Leg **R** and Lower Legs **S** using 1-M8x40mm **BLUE Bolt** **40** at each point. Attach Braces to the **OUTSIDE** of the Brackets.

WITH THE HELP AT AT LEAST TWO OTHER PEOPLE, TURN THE TRIPOD SO THAT THE HANDLE RAILS ARE FACING UP AND THE REAR LEG BRACES ARE ON THE GROUND.




16

Insert Top Ladder Section **U** into Handle Rails **H**. The brackets on the Ladder Section **MUST** be facing towards the inside of the stand. Secure using **1-M8x45mm YELLOW Bolt (45)** on each side.

17


Insert Bottom Ladder Section **V** into Top Ladder Section **U**. The brackets on the Ladder Section **MUST** be facing towards the inside of the stand. Secure using **1-M8x45mm YELLOW Bolt (45)** on each side.



18


Insert Foot **X** into Lower Leg **S**. The Foot is adjustable so you can raise or lower the stand as needed. Insert **1-M8x55mm BLACK Bolt (55)** to secure.

WITH THE HELP OF AT LEAST TWO OTHER PEOPLE, STAND THE TRIPOD UPRIGHT





18

Attach another Cross Brace **W** to Top Ladder Section **U** and Lower Leg **S**. Attach the same Cross Brace to Bottom Ladder Section **V** and Upper Leg **R** using **1-M8x40mm BLUE Bolt (40)** at each point. **Attach Braces to the OUTSIDE of the Brackets.**



19

Attach the last Cross Brace **W** to Top Ladder Section **U** and Lower Leg **S**. Attach the same Cross Brace to Bottom Ladder Section **V** and Upper Leg **R** using **1-M8x40mm BLUE Bolt (40)** at each point. **Attach Braces to the OUTSIDE of the Brackets.**



20

Insert Anchor Pin **Y** through the hole on each Foot **X** when the stand is in desired position.

21

Now that assembly is complete, go back and tighten all of the bolts with a wrench.

Be careful not to overtighten the bolts.

WARNING

MAKE SURE ALL BOLTS ARE TIGHT BEFORE PROCEEDING TO INSTALLATION



WARNING

Failure to follow all warnings listed below could result in serious injury or death.

DO NOT use this tripod without reading and following all warnings and instructions before each use. Failure to do so may result in serious injury or death.

ALWAYS inspect your tripod before each use and **DO NOT** use if parts are missing, worn, or damaged.

DO NOT exceed the tripod's **300 lbs.** weight limit, which includes your body weight as well as the weight of your clothes and gear. Exceeding the tripod's weight limit may cause the tripod to break or fail resulting in serious injury or death.

NEVER stand on tripod seat, footrest, armrest, or shooting rail. Standing on any of these parts may cause the tripod to break or fail resulting in serious injury or death.

NEVER make any alterations or modifications to the tripod. Doing so may result in serious injury or death and void all warranties.

NEVER use tripod during inclement weather. **DO NOT** use tripod during thunderstorms or any other weather conditions that include (but not limited to) lightning, freezing rain, high winds that could create slippery or dangerous conditions.

DO NOT use this tripod under the influence of alcohol, illegal substances or medication. Using tripod under the influence of alcohol, illegal substances or medication may result in serious injury or death.

NEVER use tripod if you have dizzy spells, a heart problem, are afraid of heights, have been advised by a doctor or other health care provider not to climb, or have any condition that would impair your ability to climb up or down or use tripod as it could result in serious injury or death.

NEVER remove or deface tripod warning labels. Replacement labels can be obtained from the address below.

Manufactured in the year 2020 Primal Vantage Company Inc. 2407 W. Euclid Ave., Littleton, CO 80120 1-866-972-6168

