



Instructions for linking Pee Pods

Equipment required



Drill



26mm Hole Cutter



Male Cam Fitting x2



Cam Cap x2



Link pipe

Linking Kit parts

Step 1

Using a 26mm Hole Cutter, drill a hole through the Pee Pod in the centre of the brass threaded insert. Take care not to damage the thread.

Step 2

Repeat the procedure with the other Pee Pod.

Step 3

Now screw a male cam fitting into each brass threaded insert. Using PTFE tape will ensure there are no leaks.

Step 4

Your Pee Pods can now be linked together using the link pipe provided or they can stand alone if you attach the cam caps onto the male cam fittings.

Warning!

Once the Pee Pod has been adapted to be linkable, please DO NOT stack the lower half with the cam lock cover in place. The screw-in male cam fitting can be left in place but leaving the cam lock cover in place will cause damage to the fitting if the units are stacked.

