

# Maintenance

## Maintenance Specifications for materials used in Wallprotex™ Wall Protection Products

### Initial Clean Up:

Once installation is complete, the installer must make sure that all of the wall protection sheet and profiles are clean and free of any blemishes. Layout marks and surface blemishes can be removed with mild detergents and water (see recommended detergents/cleaners below). Remove all excess adhesive using the methods and materials recommended by the adhesive manufacturer. Use a clean cloth and water to rinse these areas thoroughly, and blot dry with a damp cloth to prevent water marks and streaking.

### Routine Cleaning:

To clean Wallprotex vinyl wall guards, vinyl and clear corner protectors, vinyl corner guards, and injection molded products use a soft damp cloth or chamois to gently wipe the profile surface. Soap and lukewarm water should be used to remove light dirt. The profile should then be rinsed thoroughly with a clean cloth and water. Once washing and rinsing are complete dry the profile by blotting with a damp cloth or chamois in order to prevent streaking or water marks.

### Recommended Cleaning Products for Routine Cleaning:

Fantastik®	Green Works® All Purpose	Joy® Detergent	Pine - Sol®
Formula 409®	Johnsons Pledge®	Mr. Clean®	Spic & Span®

### The Following Cleaners are Not Recommended:

Abrasives	Gasoline	Johnson's Price	Liquid All®
Dynamo	Goof-Off® "The Miacle Cleaner"	Ketones	Tetrahydrofuran
Endust®	Isopar K	Lestoil®	Wisk®

### Spot Cleaning:

For tough stains such as spills, pencil marks, marker, and rubber heel marks the use of the following products is acceptable:

- Clorox® Clean-Up with Bleach
- Zep® Heavy Duty Citrus Degreaser
- Mr. Clean® Magic Eraser
- Antibacterial Fantastik® All Purpose Heavy Duty

Spray products on the effected area and wipe with a damp cloth or chamois. A short stiff brush may be required to remove some stains from the textured vinyl surface. The area must then be thoroughly rinsed with a clean cloth and water to remove any cleaning product residue. Dry the profile by blotting a damp clean cloth or chamois in order to prevent streaking or watermarks.

### Do not use any of the following at any time to clean Wallprotex profiles:

- Scotch-Brite™ Pads
- S.O.S.® Pads
- Brillo® Pads
- Steel Wool