



## QUICK REFERENCE REPAIR AND COATING COVERAGE GUIDE





Metal Roofing	Coverage	5-Gal. Pails/Square	Cure Time Before Rain	Substrate Cleaner Required	Application Acceptable to Wet or Dry Surface?	Primer Required?	Application Process
<b>Cleaning</b>							
799 Wash-N-Prep	1 Qt. Cleans 16 Sqs.	1 Qt. Bottle Cleans 16 Sqs.					Pressure Washer / Stiff Brush
<b>Repairs</b>							
502MS Karna-Flex (White or Gray)	25 Lin. Ft. per Gal. with 4" wide 5540 Resat-Mat Or 20 Lin. Ft. per Gal. with 6" wide 5540 Resat-Mat		20 Min.	799 Wash-N-Prep & Pressure Wash (When coating/repairing entire roof) or Denatured Alcohol or Acetone (Spot repair)	Wet or Dry	No	Chip Brush
505MS Karna-Flex with Acrylic Based Systems	25 Lin. Ft. per Gal. with 4" wide 5540 Resat-Mat Or 20 Lin. Ft. per Gal. with 6" wide 5540 Resat-Mat		24 Hours	799 Wash-N-Prep & Pressure Wash (When coating/repairing entire roof) or Denatured Alcohol or Acetone (Spot repair)	Dry	No	Chip Brush
502MS Karna-Flex or 505MS Karna-Flex WB	50 Lin. Ft. per Gal. without Fabric in 6" width		20 Min. - 502MS 24 Hours - 505MS	799 Wash-N-Prep & Pressure Wash (When coating/repairing entire roof) or Denatured Alcohol or Acetone (Spot repair)	Wet or Dry - 502 MS Dry - 505MS	No	Chip Brush
502MS Karna-Flex or 505MS Karna-Flex WB	250 Fasteners per Gallon			799 Wash-N-Prep & Pressure Wash (As indicated above)	Dry	No	Caulk Tube / Bulk Loading Applicator
5540 Resat-Mat	4" x 300' per Roll						
5540 Resat-Mat	6" x 300' per Roll						
<b>Coating</b>							
<b>Aluminum</b>							
298 Alumin-R	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
<b>Solvent-Based</b>							
502RC-W Self-Priming Base Coat	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	12-24 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
502RC-W Elasto-Kote Finish	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	12-24 Hours	N/A, Applied over Base Coat	Dry	Yes, 502 Base	Spray / Roll / Brush
<b>Acrylic-Based</b>							
404 Corrosion Proof Base Coat	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	12 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
Option 1 501 Elasto-Brite (Premium)	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	N/A, Applied over Base Coat	Dry	Yes, 404 Base	Spray / Roll / Brush
Option 2 529 Renu-White (Economy)	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	N/A, Applied over Base Coat	Dry	Yes, 404 Base	Spray / Roll / Brush
Option 3 535 QS Enviro-lastic (Quick Set)	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	20 Min.	N/A, Applied over Base Coat	Dry	Yes, 404 Base	Spray / Roll / Brush
<b>Silicone</b>							
180 Karna-Sil Epoxy Primer (A&B)	250 Sq. Ft. per Gal.	Approx. 25 Sqs. per 10-Gal (5-Gal. Part A + 5-Gal. Part B)	3 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
670HS Karna-Sil Ultra	1.5 - 3.0 Gal. per Sq	Approx. 1.5 - 3 Sqs. per 5-Gal Pail	24 Hours	N/A, Applied over Epoxy Primer	Dry	Yes, 180 Epoxy Primer	Spray / Roll / Brush
<b>Miscellaneous</b>							
45 Sky-Kote For Skylights Restoration	1 - 2 Gal. per Sq	Approx. 2.5 - 5 Sqs. per 5-Gal Pail	24 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush

## BUR / Modified Bitumen Roofing

	Coverage	5-Gal. Pails/Square	Cure Time Before Rain	Substrate Cleaner Required	Application Acceptable to Wet or Dry Surface?	Primer or Base Coat Required?	Application Process
<b>Cleaning</b>							
799 Wash-N-Prep	1 Qt. Cleans 16 Sqs.	1 Qt. Bottle Cleans 16 Sqs.					Pressure Washer / Stiff Brush
<b>Repairs</b>							
19 Ultra Flashing Cement Wet/Dry	12 Lin. Ft. with 4" wide 31 Fiberglass Membrane/Gallon		0 Min.	Remove Dirt and Debris	Wet or Dry	No	Trowel
	9 Lin. Ft. with 6" wide 31 Fiberglass Membrane/Gallon		0 Min.	Remove Dirt and Debris	Wet or Dry	No	Trowel
	24 Lin. Ft. without Fabric in 6" width/Gallon		0 Min.	Remove Dirt and Debris	Wet or Dry	No	Trowel
229AR Elastomeric Trowel Grade	12 Lin. Ft. with 4" wide 31 Fiberglass Membrane/Gallon		20 Min.	Remove Dirt and Debris	Dry	No	Trowel
	9 Lin. Ft. with 6" wide 31 Fiberglass Membrane/Gallon		20 Min.	Remove Dirt and Debris	Dry	No	Trowel
	24 Lin. Ft. without Fabric in 6" width/Gallon		20 Min.	Remove Dirt and Debris	Dry	No	Trowel
502MS Karna-Flex (White, Gray or Black)	25 Lin. Ft. with 4" wide or 20 Lin. Ft. with 6" wide 5540 Resat-Mat per Gallon		20 Min.	Remove Dirt and Debris	Wet or Dry	No	Chip Brush
505MS Karna-Flex WB with Acrylic Based System	25 Lin. Ft. with 4" wide or 20 Lin. Ft. with 6" wide 5540 Resat-Mat per Gallon		24 Hours	Remove Dirt and Debris	Dry	No	Chip Brush
	50 Lin. Ft. without Fabric in 6" width per Gallon		24 Hours	Remove Dirt and Debris	Wet or Dry - 502MS / Dry 505MS	No	Chip Brush
5540 Resat-Mat	4" x 300' per Roll						
5540 Resat-Mat	6" x 300' per Roll						
<b>Solvent-Based Primer / Emulsion Primer</b>							
220 Fibered Emulsion (For Alligatored Surfaces)	4 Gal. per Sq.	Approx. 1.25 Sqs. per 5-Gal Pail	24 Hours	No / Free of Loose Dirt	Dry	No	Spray / Roll / Brush
<b>Coating</b>							
<b>Asphalt Based</b>							
229AR Elastomeric Brush Grade over Mod. Bit. or Smooth BUR	3 Gal. per Sq.	Approx. 1.5 Sqs. per 5-Gal Pail	24 hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
298 Alumin-R over 229AR Elastomeric Brush Grade <small>(Allow 30-45 day cure time) or 220 Fibered Emulsion (allow 7-10 day cure time)</small>	2 Gal. per Sq.	Approx. 2.5 Sqs. per 5-Gal Pail	24 hours	No / Free of Loose Dirt and Residue	Dry	220 or 229AR	Spray / Roll / Brush
298 Alumin-R over Existing Aluminum Coated Surface	2 Gal. per Sq.	Aprox 2.5 Sqs. per 5-Gal Pail	24 hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
<b>Silicone Based</b>							
180 Karna-Sil Epoxy Primer (A&B) (Opt 1)	75-150 Sq. Ft. per Gal.	Approx. 7-15 Sqs. per 10-Gal Kit (5-Gal. Part A + 5-Gal. Part B)	3 hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
405 Bond-N-Shield Base Coat (Opt 2)	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
670HS Karna-Sil Ultra	1.5 - 3 Gal. per Sq.	Approx 1.5 - 3 Sqs. per 5-Gal Pail	24 Hours	NA, Applied over Epoxy Primer or Base Coat	Dry	Yes, 180 Epoxy Primer or 405 Base Coat	Spray / Roll / Brush
<b>Acrylic-Based</b>							
405 Bond-N-Shield Base Coat	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
501 Elasto-Brite	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	N/A, Applied over Base Coat	Dry	Yes, 405 Base	Spray / Roll / Brush





<b>TPO/PVC/HYPALON/Concrete Roofing</b>	Coverage	5-Gal. Pails/Square	Cure Time Before Rain	Substrate Cleaner Required	Application Acceptable to Wet or Dry Surface?	Primer Required?	Application Process
<b>Cleaning</b>							
799 Wash-N-Prep	1 Qt. Cleans 16 Sqs.	1 Qt. Bottle Cleans 16 Sqs.					Pressure Washer / Stiff Brush
<b>Repairs</b>							
502MS Karna-Flex (Any Color)	25 Lin. Ft. per Gal. with 4" wide 5540 Resat-Mat Or 20 Lin. Ft. per Gal. with 6" wide 5540 Resat-Mat		0 Min.	799 Wash-N-Prep & Pressure Wash (When coating/repairing entire roof) or Denatured Alcohol or Acetone (Spot repair)	Wet or Dry	No.	Chip Brush
505MS Karna-Flex WB with Acrylic Bases System	25 Lin. Ft. per Gal. with 4" wide 5540 Resat-Mat Or 20 Lin. Ft. per Gal. with 6" wide 5540 Resat-Mat		24 Hours	799 Wash-N-Prep & Pressure Wash (When coating/repairing entire roof) or Denatured Alcohol or Acetone (Spot repair)	Dry	No	Chip Brush
502MS Karna-Flex or 505MS Karna-Flex WB	50 Lin. Ft. per Gallon without Fabric in 6" width		20 Min. - 502MS 24 Hours - 505MS	799 Wash-N-Prep & Pressure Wash (When coating/repairing entire roof) or Denatured Alcohol or Acetone (Spot repair)	Wet or Dry - 502MS / Dry 505MS	No	Chip Brush
5540 Resat-Mat	4" x 300' per Roll						
5540 Resat-Mat	6" x 300' per Roll						
<b>Coating</b>							
<b>Solvent Based</b>							
502RC-W Self-Priming Base Coat	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	12-24 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
502RC-W Elasto-Kote Finish	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	12-24 Hours	N/A, Applied over Base Coat	Dry	Yes, 502 Base	Spray / Roll / Brush
<b>Silicone</b>							
180 Karna-Sil Epoxy Primer (A&B)	300 Sq. Ft. per Gal.	Approx. 30 Sqs. per 10-Gal Kit (5-Gal. Part A + 5-Gal. Part B)	3 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
670HS Karna-Sil Ultra	1.5 - 3 Gal. per Sq.	Approx. 1.5 - 3 Sqs. per 5-Gal Pail	24 Hours	N/A, Applied over Epoxy Primer	Dry	Yes, 180 Epoxy Primer	Spray / Roll / Brush
<b>Acrylic Based</b>							
406 Tru-Grip Base Coat	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	799 Wash-N-Prep	Dry	No	Spray / Roll / Brush
501 Elasto-Brite	1.5 Gal. per Sq.	Approx. 3 Sqs. per 5-Gal Pail	24 Hours	N/A, Applied over Base Coat	Dry	Yes, 406 Base	Spray / Roll / Brush

## EPDM Roofing

Coverage

5-Gal. Pails/Square

Cure Time Before Rain

Substrate Cleaner  
Required

Application Acceptable to  
Wet or Dry Surface?

Primer  
Required?

Application Process

### Cleaning

507 SPC Primer/Wash

0.2 gal per Sq.

5-Gal. Pail Cleans 25 Sqs.

Hudson-type Sprayer / Pressure Washer / Stiff Brush

### Repairs

502MS Karna-Flex

25 Lin. Ft. per Gal. with 4" wide 5540 Resat-Mat  
Or 20 Lin. Ft. per Gal. with 6" wide 5540 Resat-Mat

20 Min.

507 SPC Primer/Wash & Pressure Wash  
(When coating/repairing entire roof) or  
Denatured Alcohol or Acetone (Spot repair))

Wet or Dry

No

Chip Brush

505MS Karna-Flex WB  
with Acrylic Based Systems

25 Lin. Ft. per Gal. with 4" wide 5540 Resat-Mat  
Or 20 Lin. Ft. per Gal. with 6" wide 5540 Resat-Mat

24 Hour

507 SPC Primer/Wash & Pressure Wash  
(When coating/repairing entire roof) or  
Denatured Alcohol or Acetone (Spot repair))

Dry

No

Chip Brush

502MS Karna-Flex or 505MS Karna-Flex WB

50 Lin. Ft. per Gal. without Fabric in 6" Width

20 Min. - 502MS  
24 Hours - 505MS

507 SPC Primer/Wash & Pressure Wash  
(When coating/repairing entire roof) or  
Denatured Alcohol or Acetone (Spot repair))

Wet or Dry - 502MS / Dry 505MS

No

Chip Brush

5540 Resat-Mat

4" x 300' per Roll

5540 Resat-Mat

6" x 300' per Roll

### Coating

#### Solvent Based - 3 Step System

STEP 1 "Prime-Coat" of 502RC-W Gray Base Coat

0.5 Gal per Sq

Approx. 10 Sqs. per 5-Gal Pail

12-24 hours

507 SPC Primer / Wash

Dry

Yes, 507 SPC  
Primer/Wash

Spray / Roll / Brush

STEP 2 502RC-W Gray Base Coat

1.5 Gal. per Sq.

Approx. 3 Sqs. per 5-Gal Pail

12-24 hours

N/A, Applied over "Prime-Coat"

Dry

No 502 Base  
"Prime Coat"

Spray / Roll / Brush

STEP 3 502RC-W Elasto-Kote Finish

1.5 Gal. per Sq.

Approx. 3 Sqs. per 5-Gal Pail

12-24 hours

N/A, Applied over Base Coat

Dry

Yes, 502 Base

Spray / Roll / Brush

#### Silicone Based

180 Karna-Sil Epoxy Primer (A&B)

300 Sq. Ft. per Gal.

Approx. 30 Sqs. per 10-Gal Kit  
(5-Gal. Part A + 5-Gal. Part B)

3 Hours

507 SPC Primer / Wash

Dry

No

Spray / Roll / Brush

670HS Karna-Sil Ultra

1.5 - 3 Gal. per Sq Ft.

Approx. 1.5 - 3 Sqs. per 5-Gal Pail

24 Hours

NA, Applied over Epoxy Primer

Dry

Yes, 180 Epoxy Primer

Spray / Roll / Brush

#### AcrylicBased

407 EPDM & SPF Base Coat

1.5 Gal. per Sq.

Approx. 3 Sqs. per 5-Gal Pail

24 Hours

507 SPC Primer / Wash

Dry

No

Spray / Roll / Brush

501 Elasto-Brite

1.5 Gal. per Sq.

Approx. 3 Sqs. per 5-Gal Pail

24 Hours

No

Dry

Yes, 407 Base

Spray / Roll / Brush



## Film Thickness

Wet Film			Dry Film			
Gallons Per 100 SF	Mils	Inches	Emulsions		Solvent	
			Mils	Inches	Mils	Inches
1/2	8		4		6	
1	16	1/64	8		12	
1 1/2	24		12		18	1/64
2	32	1/32	16	1/64	24	
2 1/2	40		20		30	1/32
3	48		24		36	
4	64	1/16	32	1/32	48	
5	80		40		60	1/16
6	96		48		72	
7	112		56		84	
8	128	1/8	64	1/16	96	

## Application Temperature Recommendations

Product Group	Recommended Storage Temp.		Required Application Temp. Range
	Min.	Max.	
Water Based Emulsions	50° F	90° F	*40° F - 120° F
Solvent Based Adhesives	50° F	90° F	**40° F - 120° F
Solvent Based Coatings & Cements	50° F	90° F	**40° F - 120° F
Polyamine/Urethane Coatings	40° F	80° F	***40° F - 100° F
Coal Tar Based Coatings	50° F	100° F	*40° F - 100° F
Aluminum Coatings	50° F	90° F	*50° F - 120° F
Acrylic Coatings	50° F	90° F	***40° F - 120° F

\* The substrate, product and the ambient temperatures must be above minimum temperature.

\*\* Application at temperatures lower than 40°F will become difficult, due to the increase in viscosity that occurs when the product temperature is lowered. Application of product at or below freezing temperatures could result in adhesive failure, unless special precautions are taken to ensure that the surface is free of moisture and/or ice crystals.

\*\*\* Apply at ambient air temperatures 5°F above dew point.

At time of manufacture, all containers were filled at the designated quantity. However, due to the reduction in volume that occurs after cooling, settling and other environmental factors, the actual volume may be less. Please see front panel of each container for content information.



## Spray Tip Information & Recommendations

KARNAK Product	Tip Size Range	Working Pressure	*Hose ID Tested	Recommended Overspray During Application
#16	.049-.053	4000	1/2"	
#27	.039-.043	1500	1/2"	20%
#28	.023-.027	1500	1/2"	
#40	.043-.047	1800	1/2"	
#50	.043-.047	1800	1/2"	
#71	.049-.053	4000	1/2"	
#78	.049-.053	4000	1/2"	
#83 Spray	.049-.053	4000	1/2"	
#97	.039-.043	1500	1/2"	20%
#98	.039-.043	1500	1/2"	20%
#108	.029-.033	2500	1/2"	
#112	.031-.035	2500	1/2"	
#169	.023-.027	1500	1/2"	
#198	.049-.053	4000	1/2"	
#220	.045-.049	1800	1/2"	
#229 Spray	.039-.043	4000	1/2"	30%
#298	.043-.047	1700	1/2"	10%
#404	.023-.027	1800	1/2"	30%
#405	.023-.027	1800	1/2"	30%
#406	.023-.027	1800	1/2"	30%
#501	.043-.045	1800	1/2"	30%
#502 Base	.029-.033	3300	1/2"	
#502	.029-.033	2300	1/2"	
#529	.023-.027	1800	1/2"	30%
#535	.023-.027	1800	1/2"	30
#670HS	.030-.035	3500	3/4"	

\*Hose length used for testing was 81'.

Products applied using a Graco GH 833 Airless Sprayer and 1/2" diameter hose (670HS applied using GH 933 and 3/4" hose). Contact spray equipment manufacturer for more complete information.

First 100' of hose using a Graco GH833 Airless Sprayer and 1/2" diameter hose. Contact spray equipment manufacturer for more information.

Better to increase tip size first before increasing pressure to eliminate overspray.





Customer / Technical Service:  
330 Central Avenue  
Clark, NJ 07066  
(800) 526-4236  
info@karnakcorp.com  
www.karnakcorp.com

Manufacturing/Warehouse Locations:  
Clark, NJ  
Ft. Lauderdale, FL  
Broadview, IL  
Kingman, AZ

Distribution Warehouse Locations:  
Renton, WA  
Rancho Cucamonga, CA  
Dallas, TX

